




TRANSPORT – GRUE – DEMENAGEMENT INDUSTRIEL – MANUTENTION – LOCATION – ENTREPOSAGE




Camion-Grue HMF 85 tm 8520-OK6

Tableau de Charge : Flèche Principale






TRANSPORT – GRUE – DEMENAGEMENT INDUSTRIEL – MANUTENTION – LOCATION – ENTREPOSAGE



Camion-Grue HMF 85 tm 8520-OK6

Tableau de Charge : AVEC JIB FJ2000k4





HAVART

TRANSPORTS MANUTENTION

Rue de Heuseux, 42 – 4630 MICHEROUX
Tel : 04/ 377.37.54 – Fax : 04/ 377.55.57
www.havart.be email : info@havart.be

TRANSPORT – GRUE – DEMENAGEMENT INDUSTRIEL – MANUTENTION – LOCATION – ENTREPOSAGE



Numéro Havart : C9

Portée : 3820 kg à 16,80m

Portée JIB : 1 520kg à 25m

Charge utile : 6000 kg

Charge utile avec remorque 6m: 14to

Poids à vide : 26000kg

Dimensions hors tout sur route :

11,20 x 2,50 x 3,65 ou 3,90m avec Jib

Dimensions avec stabilisateurs L*I :

11,20 x 8,80 m (7,10m béquilles arrières)

Plateau de chargement : 6,30x2,45m

Hauteur plateau : 1,20/1,15m avt/arr

DIMENSIONS






HAVART

TRANSPORTS MANUTENTION

Rue de Heuseux, 42 – 4630 MICHEROUX
Tel : 04/ 377.37.54 – Fax : 04/ 377.55.57
www.havart.be email : info@havart.be

TRANSPORT – GRUE – DEMENAGEMENT INDUSTRIEL – MANUTENTION – LOCATION – ENTREPOSAGE





HAVART

TRANSPORTS MANUTENTION

Rue de Heuseux, 42 – 4630 MICHEROUX
Tel : 04/ 377.37.54 – Fax : 04/ 377.55.57
www.havart.be email : info@havart.be

TRANSPORT – GRUE – DEMENAGEMENT INDUSTRIEL – MANUTENTION – LOCATION – ENTREPOSAGE

